

## SECTION 22 3500 - DOMESTIC-WATER HEAT EXCHANGERS

### PART 1 - GENERAL

#### 1.1 RELATED DOCUMENTS

- A. Drawings and general provisions of the Contract, including General and Supplementary Conditions and Division 01 Specification Sections, apply to this Section.

#### 1.2 SUMMARY

- A. Section Includes:
  - 1. Shell-and-tube, domestic-water-in-coil, domestic-water heat exchangers.
  - 2. Domestic-water, heat-exchanger accessories.

#### 1.3 PERFORMANCE REQUIREMENTS

- A. Seismic Performance: Domestic-water heat exchangers shall withstand the effects of earthquake motions determined according to ASCE/SEI 7.
  - 1. The term "withstand" means "the unit will remain in place without separation of any parts from the device when subjected to the seismic forces specified and the unit will be fully operational after the seismic event."

#### 1.4 ACTION SUBMITTALS

- A. Product Data: For each type and size of domestic-water heat exchanger indicated. Include rated capacities, operating characteristics, electrical characteristics, and furnished specialties and accessories.
- B. Shop Drawings:
  - 1. Wiring Diagrams: For power, signal, and control wiring.

#### 1.5 INFORMATIONAL SUBMITTALS

- A. Seismic Qualification Certificates: For domestic-water heat exchangers, accessories, and components, from manufacturer.
  - 1. Basis for Certification: Indicate whether withstand certification is based on actual test of assembled components or on calculation.
  - 2. Dimensioned Outline Drawings of Equipment Unit: Identify center of gravity and locate and describe mounting and anchorage provisions.

3. Detailed description of equipment anchorage devices on which the certification is based and their installation requirements.

B. Product Certificates: For each type of shell-and-tube, domestic-water heat exchanger, from manufacturer.

C. Domestic-Water, Heat-Exchanger Labeling: Certified and labeled by testing agency acceptable to authorities having jurisdiction.

D. Source quality-control reports.

E. Field quality-control reports.

F. Warranty: Sample of special warranty.

#### 1.6 CLOSEOUT SUBMITTALS

A. Operation and Maintenance Data: For domestic-water heat exchangers to include in emergency, operation, and maintenance manuals.

#### 1.7 QUALITY ASSURANCE

A. Electrical Components, Devices, and Accessories: Listed and labeled as defined in NFPA 70, by a qualified testing agency, and marked for intended location and application.

B. ASHRAE/IESNA 90.1 Compliance: Applicable requirements in ASHRAE/IESNA 90.1.

C. ASME Compliance: Where ASME-code construction is indicated, fabricate and label heat-exchanger storage tanks to comply with ASME Boiler and Pressure Vessel Code: Section VIII, Division 1.

D. NSF Compliance: Fabricate and label equipment components that will be in contact with potable water to comply with NSF 61, "Drinking Water System Components - Health Effects."

#### 1.8 COORDINATION

A. Coordinate sizes and locations of concrete bases with actual equipment provided.

#### 1.9 WARRANTY

A. Special Warranty: Manufacturer's standard form in which manufacturer agrees to repair or replace components of domestic-water heat exchangers that fail in materials or workmanship within specified warranty period.

1. Failures include, but are not limited to, the following:

a. Structural failures including heat exchanger, storage tank, and supports.

b. Faulty operation of controls.

c. Deterioration of metals, metal finishes, and other materials beyond normal use.

2. Warranty Periods: From date of Substantial Completion.
  - a. Shell-and-Tube, Domestic-Water Heat Exchangers:
    - 1) Tube Coil: One year.
    - 2) Controls and Other Components: One year.
  - b. Compression Tanks: One year.

## PART 2 - PRODUCTS

### 2.1 SEMI-INSTANTANEOUS DOMESTIC-WATER HEAT EXCHANGERS

#### A. Semi-Instantaneous, Domestic-Water Heat Exchangers:

1. Manufacturers: Subject to compliance with requirements, provide products by one of the following:
  - a. PVI Industries, LLC
  - b. Patterson-Kelley; a division of Harsco Corporation
  - c. Ajax Boiler Inc.
2. Description: Packaged, small-capacity hot-water storage tank with heat-exchanger coil; circulator; controls; and specialties for heating domestic water with steam in coil.
3. Storage-Tank Construction: ASME-code steel with 150-psig (1035-kPa) working-pressure rating. Include nozzle and head for heat-exchanger tube coil.
  - a. Configuration: Vertical.
  - b. Tappings: Factory fabricated of materials compatible with tank. Attach tappings to tank before testing and labeling.
    - 1) NPS 2 (DN 50) and Smaller: Threaded ends according to ASME B1.20.1.
    - 2) NPS 2-1/2 (DN 65) and Larger: Flanged ends according to ASME B16.5 for steel and stainless-steel flanges and according to ASME B16.24 for copper and copper-alloy flanges.
  - c. Lining: Nickel plate complying with NSF 61 barrier materials for potable-water tank linings, including extending lining into and through tank fittings and outlets. Provide secondary overcoat of Polyshieldpolymeron interior of vessel.
  - d. Insulation: Complying with ASHRAE/IESNA 90.1, unless otherwise indicated, and suitable for operating temperature. Surround entire storage tank and nozzle except connections and controls.
  - e. Anode Rods: Factory installed, magnesium, for glass lined vessels only
4. Heat-Exchanger Coil: Vented, double-wall, copper or copper-alloy U tubes with tube sheet and supporting baffles. Include heat-exchanger pressure rating equal to or greater than heating-fluid supply pressure. Provide Y strainer and F&T trap and all other required accessories for a complete operating system
5. Temperature Control: Adjustable electronic immersion operating thermostat mounted in storage-tank shell head unless otherwise indicated.

6. Safety Control: Automatic, high-temperature-limit cutoff device or system. Include automatic low-water cutoff device or system.
7. Relief Valves: ASME rated and stamped for combination temperature-and-pressure relief valves. Include one or more relief valves with total relieving capacity at least as great as heat input, and include pressure setting less than working-pressure rating of heat exchanger. Select one relief valve with sensing element that extends into storage tank.
8. Gages: Factory-mounted thermometer and pressure gage.
9. Circulating Pump: UL 778, all-bronze, centrifugal, overhung-impeller, separately coupled in-line pump as defined in HI 1.1-1.2 and HI 1.3. Include mechanical seals, 125-psig minimum working-pressure rating, and 225 deg F continuous-water-temperature rating.
  - a. Pump Control: Sensor for operating pump and control valve.
10. Support: Factory mounted on skids.

## 2.2 DOMESTIC-WATER, HEAT-EXCHANGER ACCESSORIES

### A. Domestic-Water Compression Tanks:

1. Manufacturers: Subject to compliance with requirements, provide products by one of the following:
  - a. AMTROL Inc.
  - b. Pentair Pump Group (The); Myers.
  - c. Smith, A. O. Water Products Co.; a division of A. O. Smith Corporation.
  - d. State Industries.
  - e. Taco, Inc.
2. Description: Steel pressure-rated tank constructed with welded joints and factory-installed butyl-rubber diaphragm. Include air precharge to minimum system-operating pressure at tank.
3. Construction:
  - a. Tappings: Factory-fabricated steel, welded to tank before testing and labeling. Include ASME B1.20.1 pipe thread.
  - b. Interior Finish: Comply with NSF 61 barrier materials for potable-water tank linings, including extending finish into and through tank fittings and outlets.
  - c. Air-Charging Valve: Factory installed.

B. Piping-Type Heat Traps: Field-fabricated piping arrangement according to ASHRAE/IESNA 90.1[ or **ASHRAE 90.2**].

C. Heat-Trap Fittings: ASHRAE 90.2.

D. Combination Temperature-and-Pressure Relief Valves: ASME rated and stamped. Include relieving capacity at least as great as heat input, and include pressure setting less than heat-exchanger working-pressure rating. Select relief valves with sensing element that extends into storage tank.

E. Pressure Relief Valves: ASME rated and stamped. Include pressure setting less than heat-exchanger working-pressure rating.

F. Vacuum Relief Valves: ANSI Z21.22/CSA 4.4-M.

## 2.3 SOURCE QUALITY CONTROL

- A. Factory Tests: Test and inspect domestic-water heat exchangers specified to be ASME-code construction, according to ASME Boiler and Pressure Vessel Code.
- B. Hydrostatically test domestic-water heat exchangers to minimum of one and one-half times pressure rating before shipment.
- C. Domestic-water heat exchangers will be considered defective if they do not pass tests and inspections. Comply with requirements in Section 014000 "Quality Requirements" for retesting and reinspecting requirements and Section 017300 "Execution" for requirements for correcting the Work.
- D. Prepare test and inspection reports.

## PART 3 - EXECUTION

## 3.1 DOMESTIC-WATER, HEAT-EXCHANGER INSTALLATION

- A. Domestic-Water, Heat-Exchanger Mounting: Install domestic-water heat exchangers on concrete base. Comply with requirements for concrete bases specified in [**Section 033000 "Cast-in-Place Concrete."**] [**Section 033053 "Miscellaneous Cast-in-Place Concrete."**]
  - 1. Install dowel rods to connect concrete base to concrete floor. Unless otherwise indicated, install dowel rods on 18-inch (450-mm) centers around the full perimeter of concrete base.
  - 2. For supported equipment, install epoxy-coated anchor bolts that extend through concrete base and anchor into structural concrete floor.
  - 3. Place and secure anchorage devices. Use setting drawings, templates, diagrams, instructions, and directions furnished with items to be embedded.
  - 4. Install anchor bolts to elevations required for proper attachment to supported equipment.
  - 5. Anchor heat exchangers to substrate.
- B. Install domestic-water heat exchangers level and plumb, according to layout drawings, original design, and referenced standards. Maintain manufacturer's recommended clearances. Arrange units so controls and devices needing service are accessible.
  - 1. Install shutoff valves on domestic-water-supply piping to heat exchangers and on domestic-hot-water outlet piping. Comply with requirements for shutoff valves specified in Section 220523 "General-Duty Valves for Plumbing Piping."
  - 2. Install shutoff valves on heating hot-water piping to heat exchangers. Comply with requirements for shutoff valves specified in Section 230523 "General-Duty Valves for HVAC Piping."
  - 3. Install shutoff valves on steam and condensate piping to heat exchangers. Comply with requirements for shutoff valves specified in Section 230523 "General-Duty Valves for HVAC Piping."
- C. Install domestic-water heat exchangers with seismic-restraint devices. Comply with requirements for seismic-restraint devices specified in Section 220548 "Vibration and Seismic Controls for Plumbing Piping and Equipment."

- D. Install temperature and pressure relief valves in top portion of storage-tank shells of domestic-water heat exchangers with domestic-water storage. Use relief valves with sensing elements that extend into shells. Extend relief-valve outlet, with drain piping same as domestic-water piping in continuous downward pitch, and discharge by positive air gap onto closest floor drain.
- E. Install combination temperature-and-pressure relief valves in water piping for domestic-water heat exchangers without storage. Extend relief-valve outlet, with drain piping same as domestic-water piping in continuous downward pitch, and discharge by positive air gap onto closest floor drain.
- F. Install heat-exchanger drain piping as indirect waste to spill by positive air gap into open drains or over floor drains. Install hose-end drain valves at low points in water piping for domestic-water heat exchangers that do not have tank drains. Comply with requirements for hose-end drain valves specified in Section 221119 "Domestic Water Piping Specialties."
- G. Install thermometer on each domestic-water, heat-exchanger, inlet and outlet piping, and install thermometer on each domestic-water, heat-exchanger, heating-fluid inlet and outlet piping. Comply with requirements for thermometers specified in Section 220519 "Meters and Gages for Plumbing Piping."
- H. Install pressure gages on domestic-water, heat-exchanger, heating-fluid piping. Comply with requirements for pressure gages specified in Section 220519 "Meters and Gages for Plumbing Piping."
- I. Fill domestic-water heat exchangers with water.
- J. Charge domestic-water compression tanks with air.

### 3.2 CONNECTIONS

- A. Comply with requirements for piping specified in Section 221116 "Domestic Water Piping."
- B. Comply with requirements for heating hot-water piping specified in Section 232113 "Hydronic Piping."
- C. Comply with requirements for steam and condensate piping specified in Section 232213 "Steam and Condensate Heating Piping."
- D. Drawings indicate general arrangement of piping, fittings, and specialties.
- E. Where installing piping adjacent to domestic-water heat exchangers, allow space for service and maintenance of heat exchangers. Arrange piping for easy removal of domestic-water heat exchangers.

### 3.3 IDENTIFICATION

- A. Identify system components. Comply with requirements for identification specified in Section 220553 "Identification for Plumbing Piping and Equipment."

3.4 FIELD QUALITY CONTROL

- A. Perform tests and inspections.
  - 1. Manufacturer's Field Service: Engage a factory-authorized service representative to inspect components, assemblies, and equipment installations, including connections, and to assist in testing.
  - 2. Leak Test: After installation, charge system and test for leaks. Repair leaks and retest until no leaks exist.
  - 3. Operational Test: After electrical circuitry has been energized, start units to confirm proper operation.
  - 4. Test and adjust controls and safeties. Replace damaged and malfunctioning controls and equipment.
- B. Domestic-water heat exchangers will be considered defective if they do not pass tests and inspections. Comply with requirements in Section 014000 "Quality Requirements" for retesting and reinspecting requirements and Section 017300 "Execution" for requirements for correcting the Work.
- C. Prepare test and inspection reports.

3.5 DEMONSTRATION

- A. Engage a factory-authorized service representative to train maintenance personnel to adjust, operate, and maintain shell-and-tube domestic-water heat exchangers.

**END OF SECTION 22 3500**

NORTHWESTERN UNIVERSITY  
PROJECT NAME \_\_\_\_\_  
JOB # \_\_\_\_\_

FOR: \_\_\_\_\_  
ISSUED: 03/29/2017

THIS PAGE IS INTENTIONALLY BLANK